


Care Instructions - KRABA™ Kettlebells

The KRABA™ kettlebell is a versatile tool designed to enhance fitness and strength, combining functionality with aesthetic appeal. Meticulously crafted using timeless materials such as wood, leather, and stainless steel, this kettlebell boasts a classic design that is as impressive on display as it is in use.

To preserve the long-lasting beauty and performance of your KRABA™ kettlebell, we recommend storing and using it indoors, away from harsh elements. This will protect the handcrafted materials and ensure the equipment remains in excellent condition. For optimal results and to extend the kettlebell's lifespan, always exercise with control and adhere to safe and proper techniques.

When cleaning wooden handles; dampen a soft cloth using a mixture of mild dish soap and water and wipe the surface gently (avoid using harsh chemicals or abrasive cleaners).



Use a leather conditioner (e.g. beeswax-based leather conditioner or cream) every 6-12 months to nourish the leather, remain its suppleness and to prevent cracking.

Avoid hitting weights together and careless handling of weights (such as dropping weights on the floor) that can cause impact leaving scratches and dents to the products.